HDS CLEAN Hermetic Sliding door



RENFORCED SEALING

ERGONOMY LINKED TO CLEANING AND DECONTAMINATION REQUIREMENTS

MEDICAL / HOSPITAL OPERATING THEATRES



ANTI-X VERSION RADIOPROTECTION



IMPACT RESISTANCE



EASY MAINTENANCE



HDS CLEAN ensures an hermetic closure against air, dust, chemical or bacteriological attacks.

As real defense barrier, HDS CLEAN is made for specific areas such as operating theatres, disinfection rooms, sterile or clean rooms and other places where unpolluted clean spaces are required.






HDS CLEAN


Hermetic closure against air, dust, chemical and bacteriological attacks.

Design complying with cleaning and decontamination requirements

Optimal Operation Safety

Wide choice of leaf filling







Smooth movement and airtightness

The door running is fully automatic. It is managed by the operator that lifts up the door and ensures a smooth and safe sliding movement of the leaf.

The airtightness of the leaf is ensured by a specific rubber seal making a real hermetic barrier against outside attacks.

The door rail system, located in the operator, lets the door threshold free (no rail in the floor) allowing the passage of wheelchairs or clinic beds without any shock.





When closing, the rail equipped with a specific banister, allows the leaf to lower and to flatten against the door wall frame, ensuring a perfect airtightness.

Controls and detections

A digital display unit allows to view the door report and programming modes, to set its operating mode or to adjust opening / closing speeds and hold open times. according to the user's needs.

The passage safety is ensured by a detector that avoids any collision of the leaf with the user. A flushing inside handle allows the door to open easily thanks to the Easy Coming function.

The door opening can be controlled by numerous systems (remote control, push button by foot or elbow, button without contact, detection sensor...).



Contactless switch



Active Infrarred safety




Naviblu



Visioblu and S remote control

Air permeability




Aluminium

Stainless

Melamine

Use ergonomics

A bi-flushing window can be built in to the leaf. The wall frame cover, the profiles and cover design are stylized to make the cleaning operations easier.




Leaves filling


Leaves are made of a rigid core coated with high density stratified panels. They are available in a large colour range.

Other materials or coatings are also available to meet all specific requirements (sound insulation, transparency, damp environment...).

The leaves edges are protected by an aluminium frame with smooth shapes. This makes the door most elegant. This frame has a continuous tubular seal all around the door.

The bay opening is covered with an aluminium frame fixed on the wall on which the leaf flattens while closing. An opposite wall frame can be installed to protect the passage from shocks.





Bay protection
Wall frame/opposite wall frame/
wall covering



Integrated blinds



Lifting handle



Flushing inside handle



Bi-flushing glass oculus

MECHANICS				
Installation		Surface Applied		
Structure		Aluminium		
Casing (H x P)				
	with dust free cover	278 x 201 mm		
	without dust free cover	185 x 201 mm		
		1 leaf		
Passage width min/ma	x	700 / 1800 mm		
Max passage height		2500 mm		
PERFORMANCES		Hemertic	X-ray	
Leaf weight max.		1 x 150 kg	1 x 150 kg	
Opening speed		6 to 50 cm/s	6 to 50 cm/s	
Closing speed		6 to 30 cm/s	6 to 30 cm/s	
Hold open time		1 to 25s	1 to 25s	
Opening force		6 to 23 daN	6 to 30 daN	
Closing force		6 to 15 daN	6 to 30 daN	
ELECTRICAL ENV	IDONMENT			
Power supply	INCHMENT	Mains 50-60 Hz, 230V 10% wit	h earth	
Average absorbed pov	wer	50 W		
Motor voltage / Emerg		40 Vcc / 12 Vcc (2,1 Ah)		
Relative humidity			10% to 93% without condensation	
Operating Temperature		-20°C / +60°C		
STANDARDS				
NF EN1026	Airtightness in positive or negative pression			
EC	Electromagnetic compatibility : directive 2004/108/CE, electrical safety – low tension: directive 2006/95/CEE, Machines : directive 2006/42/CE			
EN 61000-6-3	EMC : Issue for the residential, commercial environments and of the light industry			
EN 61000-6-2	EMC : Immunity for the industrial environments			
EN 60335-1/-2-103	Safety of electrodomestic devices and similar			

EQUIPMENTS / OPTIONS

FRAMES LEAF & WALL

EN 16005

Aluminium AS1 or RAL	•
X-ray proof wall frame	0

Pedestrian motorised doors : use safety

MATERIALS OR COVERING LEAF

•
0
0
0
0
0

LEAF EQUIPMENTS

Flushing glass oculus 400×400 mm or 600×400 mm	0
X-ray glass oculus 400 x 400mm or 600 x 400mm	0
Flush-mounted opening handle	
Manual opening handle for lifting	


SAFETY & DETECTION Infrared curtain

Small/Large opening control

Easy Coming

Infrared barrier	0
CONTROL DEVICES	
Switch without contact	0
Push button (by elbow, foot)	0
IR Remote Control	0

HPL COLOURS AVAILABLE ON STOCK*



* Others choices on request * Standard * Option

0



www.portalp.com